



K 4 Full Control Home

The K 4 Full Control home is the perfect partner for cleaning your patio or decking. The handy home kit comes with a T350 and a 1L bottle of stone detergent.

MISSING
PIC-
TURE: D:\
IM0027641



1 Full Control trigger gun and spray lances

- Gives you direct feedback as to the pressure setting you are on, ensuring you get the right pressure setting for the surface you are trying to clean.
- The pressure can be regulated by twisting the Vario Power spray lance until the desired level is shown.

2 Parking position for easy accessory storage at all times

- The Full Control trigger gun and the connected spray lance can be stored on the pressure washer during cleaning.
- The Full Control trigger gun is easily accessible.

3 Plug and Clean

- Quick and easy application of detergents through the pressure washer, when in detergent mode.
- The Plug and Clean detergent can be replaced quickly and easily with one simple movement.

4 Telescopic handle

- Made of high-quality aluminium.
- For a convenient pulling height.



K 4 Full Control Home

- Full Control Trigger Gun with pressure setting display
- Maximum stability thanks to low centre of gravity, hose guide and a larger base
- Highly efficient water-cooled motor

Technical data

Order Number	1.324-005.0	
EAN code	4054278130750	
Pressure	bar / MPa	20-130 / 2-13
Flow rate	l/h	420
Max. water feed temperature	°C	40
Power rating	kW	1,8
Weight without accessories	kg	11,4
Dimensions (L x W x H)	mm	0
Current type	V / Hz	230 / 50

Equipment

Home kit	T350 Patio Cleaner, 1 L 3-in-1 Stone and Facade Detergent	Adapter garden hose A3/4"	■
High-pressure gun	G 145 Q Full Control		
Vario Power spray lance	■		
Dirt Blaster spray lance	■		
High-pressure hose	m	6	
Quick Connect on machine	■		
Detergent application via	Plug and Clean system		
Telescopic handle	■		
Water-cooled motor	■		
Soft bag	■		
Integrated water filter	■		

■ Included in delivery.